


1


Room Side



Window Side

TOP FIXING

Fix brackets to ceiling or under side of recess with holes drilled on a line at least 3" (75mm) from the wall or window frame. The end brackets should be situated approximately 4" (100mm) from each end of the track. All remaining brackets should be spaced evenly between these brackets.



FACE FIXING

Fix brackets to the wall or window frame at the desired height. The brackets should be situated approximately 4" (100mm) from each end of the track. All remaining brackets should be spaced evenly between these brackets.


2

FITTING THE TRACK

The track can now be fitted into the brackets. Locate the small lip projecting from the brackets (indicated in the diagram).

Top Fixing: Push the track up into the spring brackets to hold in position.

Face Fixing: Turn the track until level and tighten the retaining screws to hold the track in position (the screws will fit into the front slot of the track).






3


FITTING THE VERTICAL SLATS

Turn the controls until the hook slots of the track are at right angles to the window.


- 1) Hang the vertical slats, keeping all seams facing the same direction.
- 2) Insert a vertical slat weight into the bottom pocket of each slat.
- 3) Attach the connecting chain by pushing the clip onto the weight post.



4



Max distance possible is 1 mtr. The chain must be fitted with a safety device creating optimum tension on both cord and chain.



Child Safety Device Installation.

The cord retaining device / safety bracket must be installed with optimum tension on both cord and chain to prevent looped cord(s) becoming slack.

Place retaining device on the wall and mark the position of the hole using a pencil.

Attach retaining device using suitable fixings ensuring the device is fully closed.

Make sure all warning labels are read and understood before removal and operation of the blind.

5

Your fabric vertical slats have been specially coated with a solution to ensure they remain flat and do not fray. To retain these qualities the fabric should not be subjected to machine washing or dry cleaning.

If cleaning is required you should:

- 1) Remove slats and wipe with a clean cloth dampened with a solution of mild detergent. (Wet-wipes are perfect for this)
- 2) Place slats between clean, dry cloths and iron lengthwise with an iron set on cool.
- 3) Re-hang the slats whilst still damp.